

Driving & Manifold Pipeline



1 Overview

The driving pipeline is installed between the driving gas bottle group and the regional selection valve and the fire extinguisher bottle group. The main function is to drive the driving gas, so that the selection valve and the fire extinguisher bottle group can be opened reliably.

The manifold pipe: When the fire happens, according to the different regional fire required dosage, the system will open different fire extinguishing agent cylinder. Each cylinder collected through pipe manifold to the corresponding region corresponding to the fire extinguishing.

2 Technical Parameter

Model	Nominal diameter	Connect thread	Nominal working pressure
Driving pipe	6mm	M14 * 1.5	20MPa